

INSTRUCTION SHEET - 97258C CANE APRON KIT

For use with Contour[®] and Soft Sides[®] models

1. REMOVE (5) SCREWS AND BOTTOM COVER PLATE.
2. ATTACH (ITEM 1) CANE APRON WITH THE (5) SCREWS PROVIDED.
3. BOTTOM COVER AND ORIGINAL SCREWS CAN BE DISCARDED.

KIT CONSISTS OF:

ITEM	PART NO.	DESCRIPTION
1	56020C	CANE APRON
2	75740C	SCREW #10 X .50

