


 Align key on back side of disc with channel in wrench handle.
Insert lock washer and screw.

3. Tighten screw with hex key/Allen

Instructions:

wrench.

RCORP3 Smooth Jaw Wrench with Corp Stop Key Disc



RCORP3 Smooth Jaw Wrench with Corp Stop Key Disc

#02117 includes #02114 RCORP wrench plus #02119 corp stop key disc assembly.

#02119 Corp Stop Key Disc Assembly includes replacement disc with 3 slots, lock washer and screw. RCORP wrench sold separately.

Slot sizes: .450", .390", .312" for use on standard and ball valve corp stop keys.

Reed Manufacturing Company 1425 West 8th Street Erie, PA 16502 USA



RCORP WRENCH 02114 NOT

INCLUDED WITH 02119

Phone: 800-666-3691 or 814-452-3691 Fax: 800-456-1697 or 814-455-1697 www.reedmfgco.com

0817-52120

Instructions

ALIGN KEY WITH CHANNEL IN WRENCH HANDLE



PIPE TOOLS & VISES SINCE 1896

Instructions:

- 1. Align key on back side of disc with channel in wrench handle.
- 2. Insert lock washer and screw.
- 3. Tighten screw with hex key/Allen wrench.

#02117 includes #02114 RCORP wrench plus #02119 corp stop key disc assembly.

#02119 Corp Stop Key Disc Assembly includes replacement disc with 3 slots, lock washer and screw. RCORP wrench sold separately.

Slot sizes: .450", .390", .312" for use on standard and ball valve corp stop keys.

Reed Manufacturing Company 1425 West 8th Street Erie, PA 16502 USA



Phone: 800-666-3691 or 814-452-3691 Fax: 800-456-1697 or 814-455-1697 www.reedmfgco.com