

<sup>&</sup>quot;NOTE: Install this product according to the installation guide. Fixture dimensions are nominal and conform to tolerances in ASME A112.19.2 - 2008/CSA B45.1-08 Standards.