


Power Scraper

MODEL HK1810



002873



INSTRUCTION MANUAL

WARNING:

For your personal safety, READ and UNDERSTAND before using. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

SPECIFICATIONS

Model	HK1810
Blows per minute	0 - 3,200
Overall length	315 mm (12-3/8")
Net weight	3.2 kg (7.0 lbs)

• Manufacturer reserves the right to change specifications without notice.

• Specifications may differ from country to country.

GENERAL SAFETY RULES

USA002-2

(For All Tools)

∆ WARNING:

Read and understand all instructions. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

SAVE THESE INSTRUCTIONS

Work Area

- 1. Keep your work area clean and well lit. Cluttered benches and dark areas invite accidents.
- 2. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- 3. Keep bystanders, children, and visitors away while operating a power tool. Distractions can cause you to lose control.

Electrical Safety

- 4. Double insulated tools are equipped with a polarized plug (one blade is wider than the other.) This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a polarized outlet. Do not change the plug in any way. Double insulation I eliminates the need for the three wire grounded power cord and grounded power supply system.
- Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is grounded.

- 6. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- 7. Do not abuse the cord. Never use the cord to carry the tools or pull the plug from an outlet. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately. Damaged cords increase the risk of electric shock.
- When operating a power tool outside, use an outdoor extension cord marked "W-A" or "W". These cords are rated for outdoor use and reduce the risk of electric shock.

Personal Safety

- 9. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use tool while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tools may result in serious personal injury.
- 10. Dress properly. Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.
- 11. Avoid accidental starting. Be sure switch is off before plugging in. Carrying tools with your finger on the switch or plugging in tools that have the switch on invites accidents.
- 12. Remove adjusting keys or wrenches before turning the tool on. A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.
- 13. Do not overreach. Keep proper footing and balance at all times. Proper footing and balance enables better control of the tool in unexpected situations.
- 14. Use safety equipment. Always wear eye protection. Dust mask, non-skid safety shoes, hard hat, or hearing protection must be used for appropriate conditions. Ordinary eye or sun glasses are NOT eye protection.

Tool Use and Care

- 15. Use clamps or other practical way to secure and support the workpiece to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control.
- 16. Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.
- 17. Do not use tool if switch does not turn it on or off. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
- 18. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.
- 19. Store idle tools out of reach of children and other untrained persons. Tools are dangerous in the hands of untrained users.
- 20. Maintain tools with care. Keep cutting tools sharp and clean. Properly maintained tools with sharp cutting edges are less likely to bind and are easier to control.
- 21. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the tools operation. If damaged, have the tool serviced before using. Many accidents are caused by poorly maintained tools.
- 22. Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool, may become hazardous when used on another tool.

SERVICE

23. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury.

24. When servicing a tool, use only identical replacement parts. Follow instructions in the Maintenance section of this manual.

Use of unauthorized parts or failure to follow Maintenance instructions may create a risk of electric shock or injury.

USE PROPER EXTENSION CORD: Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating. Table 1 shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the cord.

Ampere Rating		Volts	Volts Total length of cord in feet					
Allipen	enating	120 V	25 ft.	50 ft.	100 ft.	150 ft.		
More Than	Not More Than			AWG				
0	6		18	16	16	14		
6	10		18	16	14	12		
10	12	1	16	16	14	12		
12	16		14	12	Not Reco	mmended		

Table 1: Minimum gage for cord

SPECIFIC SAFETY RULES

USB009-2

DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to hammer safety rules. If you use this tool unsafely or incorrectly, you can suffer serious personal injury.

- Hold tools by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a "live" wire will make exposed metal parts of the tool "live" and shock the operator.
- 2. Wear ear protectors when using the tool for extended periods. Prolonged exposure to high intensity noise can cause hearing loss.
- 3. Wear a hard hat (safety helmet), safety glasses and/or face shield. Ordinary eye or sun glasses are NOT safety glasses. It

is also highly recommended that you wear a dust mask and thickly padded gloves.

- 4. Be sure the bit is secured in place before operation.
- 5. Under normal operation, the tool is designed to produce vibration. The screws can come loose easily, causing a breakdown or accident. Check tightness of screws carefully before operation.
- In cold weather or when the tool has not been used for a long time, let the tool warm up for a while by operating it under no load. This will loosen up the lubrica-

tion. Without proper warm-up, hammering operation is difficult.

- 7. Always be sure you have a firm footing. Be sure no one is below when using the tool in high locations.
- 8. Hold the tool firmly with both hands.
- 9. Keep hands away from moving parts.
- 10. Do not leave the tool running. Operate the tool only when hand-held.


- 11. Do not point the tool at any one in the area when operating. The bit could fly out and injure someone seriously.
- 12. Do not touch the bit or parts close to the bit immediately after operation; they may be extremely hot and could burn your skin.
- Some material contains chemicals which may be toxic. Take caution to prevent dust inhalation and skin contact. Follow material supplier safety data.

SAVE THESE INSTRUCTIONS

☆ WARNING:


MISUSE or failure to follow the safety rules stated in this instruction manual may cause serious personal injury.

FUNCTIONAL DESCRIPTION




- Speed control screw
- 2. Switch trigger
- 3. Higher
- 4. Lower

ASSEMBLY



1. Dust cover



^{1.} Tool retainer

△ CAUTION:

• Always be sure that the tool is switched off and unplugged before adjusting or checking function on the tool.

Switch action

▲ CAUTION:

 Before plugging in the tool, always check to see that the switch trigger actuates properly and returns to the "OFF" position when released.

To start the tool, simply pull the switch trigger. Tool speed is increased by increasing pressure on the switch trigger. Release the switch trigger to stop.

A speed control screw is provided so that maximum tool speed can be limited (variable). Turn the speed control screw clockwise for higher speed, and counterclockwise for lower speed.

▲ CAUTION:

 Always be sure that the tool is switched off and unplugged before carrying out any work on the tool.


Installing or removing the bit

To install the bit, first attach the dust cover provided to the bit as shown in the figure.

Then turn the tool retainer in the direction of the arrow and insert the bit into the tool barrel as far as it will go. Now turn the tool retainer in the opposite direction to secure the bit.

To remove the bit, follow the installation procedure in reverse.

OPERATION




Position the bit at the location to be chipped, then pull the switch trigger. Apply slight pressure on the tool so that the tool will not bounce around, uncontrolled. Pressing very hard on the tool will not increase the efficiency.


MAINTENANCE

▲ CAUTION:

 Always be sure that the tool is switched off and unplugged before attempting to perform inspection or maintenance.



- 1. Commutator
- 2. Insulating tip
- 3. Carbon brush




1. Rear cover

Replacing carbon brushes


When the resin insulating tip inside the carbon brush is exposed to contact the commutator, it will automatically shut off the motor. When this occurs, both carbon brushes should be replaced. Keep the carbon brushes clean and free to slip in the holders. Both carbon brushes should be replaced at the same time. Use only identical carbon brushes.

Use a screwdriver to remove the rear cover.



1. Screwdriver

2. Brush holder cap



Lock nut wrer
Crank cap

1. Hammer grease

Use a screwdriver to remove the brush holder caps. Take out the worn carbon brushes, insert the new ones and secure the brush holder caps.

Lubrication

This tool requires no hourly or daily lubrication because it has a grease-packed lubrication system. It should be relubricated after every 6 months of operation. Send the complete tool to Makita Authorized or Factory Service Center for this lubrication service. However, if circumstances require that you should lubricate it by yourself, proceed as follows.

Run the tool for several minutes to warm it up. Switch off and unplug the tool.

Remove the crank cap using a Makita lock nut wrench 28 (optional accessory). Rest the tool on the table with the bit end pointing upwards. This will allow the old grease to collect inside the crank housing.

Wipe out the old grease inside and replace with a fresh grease (30 g; 1 oz). Use only Makita genuine hammer grease (optional accessory). Filling with more than the specified amount of grease (approx. 30 g; 1 oz) can cause faulty hammering action or tool failure. Fill only with the specified amount of grease.

Reinstall the crank cap and tighten with the lock nut wrench.

△ CAUTION:

• Do not tighten the crank cap excessively. It is made of resin and is subject to breakage.

To maintain product SAFETY and RELIABILITY, repairs, any other maintenance or adjustment should be performed by Makita Authorized or Factory Service Centers, always using Makita replacement parts.

ACCESSORIES

△ CAUTION:

 These accessories or attachments are recommended for use with your Makita tool specified in this manual. The use of any other accessories or attachments might present a risk of injury to persons. Only use accessory or attachment for its stated purpose.

If you need any assistance for more details regarding these accessories, ask your local Makita service center.

- Bull point
- Scaling chisel
- Scraper assembly
- · Grooving chisel
- Safety goggles
- Hammer grease
- Bit grease
- Lock nut wrench 28
- Hex wrench
- Dust cover
- Steel carrying case

Memo

Memo)
------	---

Memo

First-Class Postage Required

Post Office will not deliver without proper postage.

Makita U.S.A., Inc. 14930 Northam Street La Mirada, CA 90638-5753

I.

đ

Fold

Ռեսիավիակեսիկեսիկաների

MAIL THIS PORTION

Your answers to the following questions are appreciated.

1. This product was purcha	sed from:		3. How did you learn ab	out this product:
Home Center	Other ()	Magazine	Radio
Hardware/Lumber Store			From Dealer	Exhibition
Tool Distributor			Newspaper	From Friend
Industrial Supply	Industrial Supply		Store Display	Previous Usage
Construction Supply			Catalog	Other ()
2. Use of the product is interest	ended for:		4. Most favored points	are:
Construction Trade			Design	Repair Service
Industrial Maintenance			Features	Durability
Home Maintenance	Home Maintenance			
Hobby			Price	Other ()
Other ()			Makita Brand	
5. Any comments:				
DATE PURCHASED			MODEL NO.	
MONTH	YAC	YEAR		
			SERIAL NO.	

TL. LAST N	IAME / COMPA	NY NAME				STAT Married	M	F
REET ADRES	s		I I		1 1	• •		
TY								
						AREA CODE		
		ZIP CODE		PHON	E	OODL		
STATE								
STATE								
AGE:	Under 19	20-29	30-	39 40-	49 5	0-60	Over 60)

Facsimile No: (714) 522-8133

Pacto

FACTORY SERVICE CENTERS

1-800-4-MAKITA

RETAIN THIS PORTION FOR YOUR RECORDS

ARIZONA

3707 E. Broadway Rd., Ste. 6 Phoenix, AZ 85040 (602) 437-2850

CALIFORNIA 41850 Christy St. Fremont, CA 94538-5107 (510) 657-9881

14930 Northam St. La Mirada, CA 90638-5753 (714) 522-8088

1970 Fulton Avenue Sacramento, CA 95825 (916) 482-5197

7674 Clairemont Mesa Blvd. San Diego, CA 92111 (858) 278-4471

16735 Saticoy St., Ste. 105 Van Nuys, CA 91406 (818) 782-2440

COLORADO

11839 E. 51st Ave. Denver, CO 80239-2709 (303) 371-2850 FLORIDA 750 East Sample Road Pompano Beach, FL 33064 (954) 781-6333

GEORGIA 4680 River Green Parkway NW Duluth, GA 30096 (770) 476-8911

ILLINOIS 1450 Feehanville Dr. Mt. Prospect, IL 60056-6011 (847) 297-3100

MARYLAND 7397 Washington Boulevard, Suite 104 Elkridge, MD 21075 (410) 796-4401

MASSACHUSETTS 232 Providence Hwy. Westwood, MA 02090 (781) 461-9754

MINNESOTA 6427 Penn Ave. South Richfield, MN 55423 (612) 869-5199 MISSOURI 9876 Watson Road St. Louis, MO 63126-2221 (314) 909-9889

NEBRASKA 4129 S. 84th St. Omaha, NE 68127 (402) 597-2925

NEVADA 3375 S. Decatur Blvd. Suites. 22 - 24 Las Vegas, NV 89102 (702) 368-4277

NEW JERSEY 251 Herrod Blvd. Dayton, NJ 08810-1539 (609) 655-1212

NEW YORK 4917 Genessee Street Cheektowaga, NY 14225 (716) 685-9503

OREGON 828 19th Avenue, N.W. Portland, OR 97209 (503) 222-1823 PENNSYLVANIA 1704 Babcock Blvd. Pittsburgh, PA 15209 (412) 822-7370

PUERTO RICO 200 Guayama St. Hato Rey, PR 00917 (787) 250-8776

TENNESSEE 1120 Elm Hill P. Suile 170 Nashville, TN 372 (615) 248-3321

TEXAS 12801 Stemmons Fwy Ste. 809 Farmers Branch, TX 75234 (972) 243-1150

12701 Directors Dr. Stafford, TX 77477-3701 (281) 565-8665

3453 IH-35 North, Ste. 101 San Antonio, TX 78219 (210) 228-0676

WISCONSIN

Lincoln Plaza Shopping Ctr. 2245 S. 108th St. West Allis, WI 53227 (414) 541-4776

CUSTOMER'S RECORD

When you need service: Send complete tool (prepaid) to one of the Makita Factory Service Centers listed, or to an Authorized Makita Service Center. Be sure	Date Purchased
	Dealer's Name & Address
to attach a letter to the outside of	Model No.
the carton detailing the problem with your tool.	
	Serial No.

WARNING

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

MAKITA LIMITED ONE YEAR WARRANTY

Warranty Policy

Every Makita tool is thoroughly inspected and tested before leaving the factory. It is warranted to be free of defects from workmanship and materials for the period of ONE YEAR from the date of original purchase. Should any trouble develop during this one year period, return the COMPLETE tool, freight prepaid, to one of Makita's Factory or Authorized Service Centers. If inspection shows the trouble is caused by defective workmanship or material, Makita will repair (or at our option, replace) without charge.

This Warranty does not apply where:

- repairs have been made or attempted by others:
- repairs are required because of normal wear and tear:
- the tool has been abused, misused or improperly maintained:
- alterations have been made to the tool.

IN NO EVENT SHALL MAKITA BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES FROM THE SALE OR USE OF THE PRODUCT. THIS DISCLAIMER APPLIES BOTH DURING AND AFTER THE TERM OF THIS WARRANTY.

MAKITA DISCLAIMS LIABILITY FOR ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF "MERCHANTABILITY" AND "FITNESS FOR A SPECIFIC PURPOSE," AFTER THE ONE YEAR TERM OF THIS WARRANTY.

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Makita Corporation

3-11-8, Sumiyoshi-cho, Anjo, Aichi 446-8502 Japan