







Model LS0815F Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	JM23500132	BUFFER PAD	4	
003	JM23100016	FLAT WASHER 4	4	PC.
004	JM23500008	CROSS HEAD SCREW M4X10	4	
005	JM23500009	PIVOT SHAFT	1	
006	JM23510015	BASE COMPLETE	1	
	C10 JM23500010	MITER SCALE LABEL	1	
	C20 JM2708A060	CAUTION LABEL	2	PC.
	C30 JM23500011	BASE	1	
007	JM23100013	KNOB FOR EXT.WING	2	PC.
008	JM23100025	WORKING TABLE LOCKING BRACKET	1	PC.
009	JM23100020	LOCK PLATE B	1	PC.
010	JM23100016	FLAT WASHER 4	2	PC.
011	JM23100015	SPRING WASHER 4	2	PC.
012	JM23100014	CROSS HEAD SCREW M4X15	2	PC.
013	JM23100018	LOCK PLATE A	1	PC.
014	JM23100016	FLAT WASHER 4	2	PC.
015	JM23100015	SPRING WASHER 4	2	PC.
016	JM23100014	CROSS HEAD SCREW M4X15	2	PC.
017	JM23100023	PRESS PLATE	1	PC.
018	JM23100021	LOCK SPRING	1	PC.
019	JM23100022	LOCK PIN	1	PC.
020	JM23500015	LOCK SHAFT B	1	
021	JM23500014	SPRING11	1	
022	JM23500013	ADJUSTABLE ROD	1	
023	JM23100027	MITER LOCKING HANDLE	1	PC.
024	JM23500016	LOCK SHAFT A	1	
025	JM23500012	FRICTION PLATE	2	
026	JM23510018	WORKING TABLE COMPLETE	1	
	C10 JM23500017	BEVEL SCALE LABEL	1	
	C20 JM23500018	LOCKING ROD	1	
	C30 JM23500019	WORKING TABLE	1	
	C40 JM23500020	ELASTIC PIN 4X30	1	
	C50 JM23500021	HEX NUT M10	1	
	C60 JM23180074	CAUTION LABEL	1	
	C70 JM23180075	CAUTION LABEL	1	
027	JM23500008	CROSS HEAD SCREW M4X10	1	
028	JM23100016	FLAT WASHER 4	1	PC.
029	JM23100030	MITER POINTER	1	PC.
030	JM23500053	OUT STAR WASHER	1	
031	JM23100034	HEX BOLT M6X28	3	PC.
032	JM23500023	LOCKNUT M8	1	
033	JM23500022	FLAT WASHER 8	1	
034	JM23100035	ANTI-LOOSEN RING	3	PC.
035	JM23500008	CROSS HEAD SCREW M4X10	6	
036	JM23100029	TABLE INSERT	2	PC.
039	JM23100013	KNOB FOR EXT.WING	2	PC.
040	JM23500026	RIP FENCE	1	
041	JM23100062	HEX BOLT M8X30	4	PC.
042	JM23100061	SPRING WASHER 8	4	PC.
043	JM23100060	FLAT WASHER 8	4	PC.
044	JM23500025	SUB FENCE	1	
045	JM23100065	CROSS HEAD SCREW M4X8	2	PC.

046	JM23100015	SPRING WASHER 4	2 PC.	
047	JM23100016	FLAT WASHER 4	2 PC.	
048	JM23500024	KEY	1	
049	JM23500095	45DEGREE LIMIT BRACKET	1	
050	JM23100007	FLAT WASHER 5	3 PC.	
051	JM23100149	SPRING WASHER 5	3 PC.	
052	JM23500096	H.S.BOLT M5X14	3	
053	JM23100016	FLAT WASHER 4	2 PC.	
054	JM23100015	SPRING WASHER 4	2 PC.	
055	JM23500008	CROSS HEAD SCREW M4X10	2	
056	JM23500097	45DEGREE COVER	1	
057	JM23500094	SPRING8	1	
058	JM23500093	45DEGREE LIMIT PLATE	1	
059	JM23100051	LIMITED KNOB	1 PC.	
060	JM23100049	MITER PRESSION SPRING	1 PC.	
061	JM23100052	CLAMP PLATE	1 PC.	
062	JM23510008	SUPPORT ARM COMPLTE	1	
	C10	JM23100087	LOCK SCREW M6X8	2 PC.
	C20	JM23500089	LINEAR BEARING	3
	C30	JM23100081	BUFFER	2 PC.
	C40	JM23500090	SUPPORT ARM	1
	C50	JM23500091	ANGLE LIMIT	1
	C60	JM23500092	BEARING GASKET	1
063	JM23500079	RETAINING RING 8	1	
064	JM23500078	FRICTION RING	1	
065	JM23100014	CROSS HEAD SCREW M4X15	1 PC.	
066	JM23100016	FLAT WASHER 4	1 PC.	
067	JM23100048	BEVEL POINTER	1 PC.	
068	JM23500053	OUT STAR WASHER	1	
069	JM23500080	90DEGREE LIMIT BRACKET	1	
070	JM23100086	SLIDING BAR LOCKING KNOB	1 PC.	
071	JM23100190	SPECIAL WASHER 6	1 PC.	
072	JM23100088	PRESSURE SPRING	1 PC.	
073	JM23100010	FLAT WASHER 10	2 PC.	
074	JM23100009	LOCKNUT M10	1 PC.	
075	JM23100053	BOWL TYPE PLATE	1 PC.	
076	JM23100055	BIG FLAT WASHER 10X26X2.5	1 PC.	
077	JM23100054	SURFACE BEARING	1 PC.	
078	JM23100055	BIG FLAT WASHER 10X26X2.5	1 PC.	
079	JM23500086	SUPPORT ARM COVER	1	
080	JM23100007	FLAT WASHER 5	2 PC.	
081	JM23100006	CROSS HEAD SCREW M5X20	2 PC.	
082	JM23100019	CROSS HEAD SCREW M4X18	1 PC.	
083	JM23100016	FLAT WASHER 4	1 PC.	
084	JM23500087	BEVEL LOCKING HANDLE	1	
085	JM23500088	HEX NUT	1	
086	JM23500081	CROSS HEAD SCREW M5X	1	
087	JM23100007	FLAT WASHER 5	1 PC.	
088	JM23100149	SPRING WASHER 5	1 PC.	
089	JM23500082	SUPPORT ARM COVER	1	
090	JM23500083	DUSTPROOF RING	2	
091	JM23500084	BEARING GASKET	1	
092	JM23500083	DUSTPROOF RING	2	
093	JM23500082	SUPPORT ARM COVER	1	
094	JM23100007	FLAT WASHER 5	1 PC.	
095	JM23100149	SPRING WASHER 5	1 PC.	
096	JM23500081	CROSS HEAD SCREW M5X	1	
097	JM23100019	CROSS HEAD SCREW M4X18	2 PC.	

098	JM23100016	FLAT WASHER 4	2 PC.
099	JM23100072	CORD CLAMP	1 PC.
100	JM23500066	CABLE HOLDER BRACKET	1
101	JM23500081	CROSS HEAD SCREW M5X	2
102	JM23100149	SPRING WASHER 5	2 PC.
103	JM23100007	FLAT WASHER 5	2 PC.
104	JM23100007	FLAT WASHER 5	2 PC.
105	JM23500081	CROSS HEAD SCREW M5X	2
106	JM23100149	SPRING WASHER 5	2 PC.
107	JM23500085	SLIDING BAR BRACKET	1
108	JM23100091	WRENCH CLIP	1 PC.
109	JM23100016	FLAT WASHER 4	1 PC.
110	JM23100015	SPRING WASHER 4	1 PC.
111	JM23100014	CROSS HEAD SCREW M4X15	1 PC.
113	JM23100103	WHEEL LOCK RING	1 PC.
114	JM23100102	GUARD WHEEL	1 PC.
115	JM23500031	SQUARE NECK BOLT M5X12	1
116	JM23510004	LOW BLADE GUARD	1
	C10 JM23500032	LOW BLADE GUARD	1
	C20 JM23500033	LOW GUARD SUPPORT PLATE	1
	C30 JM23100104	FLAT WASHER 5	3 PC.
	C40 JM23100101	GUARD RIVET	3 PC.
117	JM23500035	GUARD SPRING	1
118	JM23500134	HEX BOLT M8X15	1
119	JM23100113	CROSSHEAD SCREW FOR GUARD	1 PC.
120	JM23500036	LOW GUARD FIX PLATE	1
121	JM23500037	GUARD LINKAGE CENTER PLATE	1
122	JM23100007	FLAT WASHER 5	1 PC.
123	JM23100141	LOCKNUT M5	1 PC.
124	JM23500135	BLADE BOLT	1
125	JM23500038	BLADE FLANGE	2
128	JM23500039	DUST PORT	1
129	JM23100193	PIN C	1 PC.
130	JM23100193	PIN C	1 PC.
132	JM23510005	UP BLADE GUARD COMPLETE	1
	C10 JM23500046	UP BLADE GUARD	1
	C20 JM23100114	LINK PIN	1 PC.
	C30 JM23100147	BUFFER	1 PC.
133	JM23500047	GUARD INSERT	1
134	JM23100016	FLAT WASHER 4	2 PC.
135	JM23100015	SPRING WASHER 4	2 PC.
136	JM23100014	CROSS HEAD SCREW M4X15	2 PC.
137	JM23500048	LOCK PLATE	1
138	JM23100138	LOCK COVER	1 PC.
139	JM23500050	LOCK PLATE	1
140	JM23500049	LOCK SPRING5	1
141	JM23100119	LIMITED KNOB	1 PC.
142	JM23100035	ANTI-LOOSEN RING	1 PC.
143	JM23500051	HEX BOLT M6X25	1
144	JM23100035	ANTI-LOOSEN RING	1 PC.
145	JM23500052	H.S.SET SCREW	2
146	JM23100098	LINK SLEEVE	1 PC.
147	JM23510003	LINK COMPLETE	1
	C10 JM23500028	LINK	1
	C20 JM23500029	LINK PIN	1
	C30 JM23500030	BEARING 695Z	1
148	JM23100071	THIN FLAT WASHER 6	1 PC.
149	JM23100115	RETAINING RING 5	1 PC.

150	JM23500027	LOCK THIN NUT	1
151	JM23100071	THIN FLAT WASHER 6	1 PC.
152	JM23100098	LINK SLEEVE	1 PC.
153	JM23500055	LINK FIX PLATE	1
154	JM23500054	SQUARE NECK BOLT M6X14	1
155	JM23500071	H.S.BOLT M6X12	1
156	JM23100151	SPRING WASHER 6	1 PC.
157	JM23100190	SPECIAL WASHER 6	1 PC.
158	JM23500056	CROSS HEAD SCREW M4X28	2
159	JM23100016	FLAT WASHER 4	2 PC.
160	JM23500057	LAMP COVER	1
161	JM23500058	LAMP LENZ	1
162	JM23500059	SEALING RING	1
163	JM23510006	LAMP ASSY	1
	C10 JM23500060	REFLECTOR	1
	C20 JM23500061	LIGHT	1
164	JM23500128	FLAT WASHER 3	2
165	JM23500062	S.T.CROSS HEAD SCREW 9X13	2
166	JM23100019	CROSS HEAD SCREW M4X18	2 PC.
167	JM23100016	FLAT WASHER 4	2 PC.
168	JM23100072	CORD CLAMP	1 PC.
169	JM23500066	CABLE HOLDER BRACKET	1
170	JM23500008	CROSS HEAD SCREW M4X10	1
171	JM23100016	FLAT WASHER 4	1 PC.
172	JM23500077	BRACKET BACK COVER	1
173	JM23510020	UP BLADE GUARD BRACKETCOMPLETE	1
	C10 JM23500074	SILDING BAR	2
	C20 JM23500075	ELASTIC PIN 5	2
	C30 JM23500076	UP BLADE GUARD BRACKET	1
174	JM23500064	CONNECTION SHAFT	1
175	JM23500072	SPRING32	1
176	JM23500022	FLAT WASHER 8	1
177	JM23500071	H.S.BOLT M6X12	1
178	JM23100097	PIN CAP	1 PC.
179	JM23500065	SPRING BRACKET	1
180	JM23500063	SPRING SUPPORT PIN	1
189	JM23100093	PIN C	1 PC.
190	JM23100150	SEALING RING	1 PC.
191	JM23100096	DEPTH ADJUSTABLE PLATE BOLT	1 PC.
192	JM23100060	FLAT WASHER 8	1 PC.
193	JM23100094	WAVE SPRING WASHER	1 PC.
194	JM23100092	CUTTING DEPTH ADJUSTABLE PLATE	1 PC.
195	JM23500041	H.S.BOLT M6X40	4
196	JM23100151	SPRING WASHER 6	4 PC.
197	JM23100190	SPECIAL WASHER 6	4 PC.
207	JM23500103	OUTPUT SHAFT	1
208	JM23100156	KEY 5X10	1 PC.
209	JM23100157	BEARING 6304	1 PC.
210	JM23100158	RETAINING RING 20	1 PC.
211	JM23500104	GEAR WHEEL	1
212	JM23100160	RETAINING RING 16	1 PC.
213	JM23100161	OUTPUT SHAFT SCREW M8X12	1 PC.
214	JM23510011	GEAR BOX COMPLETE	1
	C10 JM23500105	GEAR BOX	1
	C20 JM23100162	BUSH	1 PC.
215	JM23100165	PROTECTION TUBE	1 PC.
216	JM23000163	POWER SUPPLY CORD	1 PC.
217	JM23100166	CORD CLAMP	1 PC.

218	JM23100193	PIN C	2 PC.	
219	JM23500108	PROTECTIVE SLEEVE	1	
221	JM23500136	TRANSFORMER	1	
222	JM23100177	BRAKE SYSTEM SWITCH KEY	1 PC.	
223	JM23100175	SWITCH LOCK PLATE	1 PC.	
224	JM23100171	TERMINAL POLE	1 PC.	
225	JM23100173	SWITCH LOCK BRACKET	1 PC.	
226	JM23100169	CAPACITOR	1 PC.	
227	JM23100179	ELECTRIC SWITCH	1 PC.	
228	JM23100176	SWITCH HANDLE SPRING	1 PC.	
229	JM23100174	SWITCH HANDLE	1 PC.	
230	JM23500110	BAFFLER RING	1	
231	JM23100027	MITER LOCKING HANDLE	1 PC.	
232	JM23500003	ARMATURE(120V)	1	
	D10	INC. 231,233		
233	JM23500111	BEARING 608	1	
234	JM23500112	DAMPING RING	1	
235	JM23500113	S.T. CROSS HEAD 4.2X65	2	
236	JM23500006	FIELD 120V	1	
237	JM23510023	MOTOR HOUSING COMPLETE	1	
	C10	JM23500114	MOTOR HOUSING	1
	C20	JM23500115	BRUSH HOLDER	2
	C30	JM23100185	H.S.SCREW M5X8	2 PC.
	C40	JM23180069	CAUTION LABEL	1 PC.
	C50	JM23180073	CAUTION LABEL	1
238	JM23500116	BRUSH COVER	2	
239	JM23500117	CARBON BRUSH	2	
240	JM23100190	SPECIAL WASHER 6	4 PC.	
241	JM23500118	CROSS HEAD SCREW M6X60	4	
242	JM23100192	SOFT STARTER	1 PC.	
243	JM23500119	MOTOR REAR COVER	1	
244	JM23100167	SELF TAPPING SCREW M4X16	5 PC.	
245	JM23500121	RIGHT HANDLE	1	
246	JM23100007	FLAT WASHER 5	3 PC.	
247	JM23500123	CROSS HEAD SCREW M5X40	3	
249	JM23500129	SWITCH BRACKET	1	
250	JM23500130	SWITCH	1	
251	JM23500131	SWITCH PROTECTIVE COVER	1	
252	JM23500120	ST CROSS HEAD SCREW 4.2X28	2	
253	JM23500107	LEFT HANDLE	1	
254	JM23180020	NAMEPLATE	1	
A01	JM23000127	HOLDER SET	2 PC.	
A02	JM23570003	SAW BLADE	1	
A03	JM23510009	WISE ASSEMBLY	1	
	C10	JM23500098	GUIDE ROD	1
	C20	JM23100152	WING KNOB,M6X10	1 PC.
	C30	JM23500099	CLAMP KNOB	1
	C40	JM27000218	LINK	1 PC.
	C50	JM27000219	PLATE	1 PC.
	C60	JM23100065	CROSS HEAD SCREW M4X8	1 PC.
	C70	JM23100016	FLAT WASHER 4	1 PC.
	C80	JM23100015	SPRING WASHER 4	1 PC.
A04	JM23510010	DUST BAG ASSY	1	
	C10	JM23500100	DUST BAG BEAM	1
	C20	JM23500101	DUST BAG CLAMP	1
	C30	JM23500102	DUST BAG	1
A05	JM27000328	TRIANGLE PLATE	1 PC.	
A06	782230-2	BOX WRENCH 13-3	1 PC.	