



Model RJ01W Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
1	346524-5	SHOE	1	
2	265035-0	COUNTERSUNK HEAD SCREW M4X1	2	PC.
3	424466-4	PROTECTOR	1	
4	257981-1	RETAINING RING (EXT)16	1	PC.
5	310496-0	DRIVING SLEEVE	1	
6	331963-2	GUIDE SLEEVE	1	
7	268094-3	PIN 3	1	PC.
8	256492-3	SHOULDER PIN 5	1	PC.
9	233345-3	COMPRESSION SPRING 6	1	PC.
10	453071-0	CONNECTING SLEEVE	1	
11	310495-2	PUSH PIN	1	
12	233025-1	COMPRESSION SPRING 2	1	PC.
13	233594-2	TORTION SPRING 17	1	
14	326113-2	BLADE GUIDE	1	
15	265910-0	HEX. SOCKET HEAD BOLT M3X12	2	PC.
16	266429-2	TAPPING SCREW 3X16	8	PC.
17	187271-7	HOUSING SET	1	
	D10	INC. 45		
18	890164-6	CAUTION LABEL	1	
19	896378-5	RJ01 NAME PLATE	1	
20	266747-8	PAN HEAD SCREW M4X14 WITH WM	5	
21	318805-7	GEAR HOUSING	1	
22	213961-7	O RING 22	1	PC.
23	346525-3	PLATE	1	
24	423424-7	SPONGE SEAL	1	
25	313220-0	SLIDER GUIDE	1	
26	313221-8	SLIDER	1	
27	326112-4	COLLARED SLEEVE 4	1	
28	141127-8	GEAR COMPLETE	1	
29	211242-3	BALL BEARING 6902ZZ	1	PC.
30	620028-8	LED CIRCUIT	1	
31	256158-5	PIN 3	1	PC.
32	629914-0	DC MOTOR	1	
33	424467-2	CAP	1	
34	650666-2	SWITCH	1	
35	643830-2	TERMINAL	1	PC.
36	345998-7	SET PLATE	1	PC.
37	453072-8	SWITCH LEVER R	1	
38	233438-6	COMPRESSION SPRING 4	1	PC.
39	453070-2	LOCK OFF LEVER R	1	
40	313219-5	LINK	1	
41	256158-5	PIN 3	1	PC.
42	141128-6	SWITCH LEVER F COMPLETE	1	
43	318806-5	GEAR HOUSING COVER	1	
45	187271-7	HOUSING SET	1	
	D10	INC. 17		
A01	B-20432	RECIPROSAW BLADE 100MM	1	PC.
A02	723063-A-5	RECIPROSAW BLADE 100MM	1	PC.
A03	DC10WB	DC10WB BATTERY CHARGER	1	
A04	BL1014	BATTERY BL1014 SET (195332-9)	2	PC.
D01	654069-2	RECEPTACLE	2	PC.
D02	654281-4	RECEPTACLE	2	PC.