

CORDLESS POWER TOOL ACCESSORIES

BATTERIES



Voltage	Cell Type	Ah	Style	Model#	Part#	Twin Pack Part#	Bulk Pack Part#
36V	Li-Ion	2.6	Slide-On	BL3626	194874-0	-	-
	Ni-MH	2.0	Slide-On	BH2420	193737-7	-	-
24V	Ni-MH	3.3	Slide-On	BH2433	193740-8	-	-
	Ni-MH	3.0	Slide-On	BH2433	193740-8	-	-
18V	Ni-Cad	1.3	Pod	PA18	194227-3	-	-
	Ni-Cad	2.0	Pod	1822	192827-3	-	-
	Ni-MH	2.6	Pod	1834	193159-1	-	-
	Ni-MH	3.0	Pod	1835	193140-2	-	-
	Li-Ion	1.5	Slide-On	BL1815	194309-1	194428-3	194604-9(10pack)
	Li-Ion	3.0	Slide-On	BL1830	194205-3	194230-4	194288-3(10pack)
14.4V	Ni-Cad	1.3	Pod	PA14	193987-4	638350-9-2	-
	Ni-Cad	1.3	Pod	1420	193062-6	-	-
	Ni-Cad	2.0	Pod	1422	192600-1	-	-
	Ni-MH	2.6	Pod	1434	193158-3	-	-
	Ni-MH	3.0	Pod	1435	193139-7	-	-
	Li-Ion	1.5	Slide-On	BL1415	194559-8	-	-
	Li-Ion	3.0	Slide-On	BL1430	194066-1	194397-8	-
12V	Ni-Cad	1.3	Pod	PA12	-	638347-8-2	638347-8
	Ni-Cad	1.3	Hybrid Stick	1210	632277-5	-	-
	Ni-Cad	1.3	Pod	1220	192681-5	-	-
	Ni-Cad	2.0	Pod	1222	192598-2	-	-
	Ni-MH	2.6	Pod	1234	193157-5	-	-
	Ni-MH	2.0	Slide-On	BH1220C	193928-0	-	-
	Ni-MH	3.3	Slide-On	BH1233C	193930-3	-	-
10.8V	Li-Ion	1.3	Stick	BL1013	194551-4	-	-
9.6V	Ni-Cad	1.3	Pod	PA09	638344-4	638344-4-2	-
	Ni-Cad	1.3	Stick	9000	632007-4	-	632009-0-10(10pack)
	Ni-Cad	1.3	Pod	9100	192019-4	-	-
	Ni-Cad	1.3	Pod	9120	192638-6	-	-
	Ni-Cad	1.7	Pod	9101	192321-5	-	-
	Ni-Cad	2.0	Stick	9002	192533-0	-	-
	Ni-Cad	2.0	Pod	9122	192596-6	-	-
	Ni-MH	2.6	Pod	9134	193156-7	-	-
	Ni-MH	2.0	Slide-On	BH9020A	193531-7	-	-
	Ni-MH	3.3	Slide-On	BH9033A	193536-7	-	-
7.2V	Ni-Cad	1.3	Stick	7000	632002-4	-	632006-0-10(10pack)
	Ni-Cad	2.0	Stick	7002	192532-2	-	-
	Li-Ion	1.0	Stick	BL7010	194356-2	-	-

BATTERY CHARGERS



	Model#	Part#	Li-Ion	Ni-MH	Ni-Cd	Voltage (V)	Amp Hour (Ah)	Description
Makstar Charger	DC24SC	DC24SC	0	0	0	7.2 - 24V	1.5 - 3.3Ah	Adaptor #193949-2 required to charge all Pod / Stick style batteries
Rapid Charger	DC18RA	DC18RA	0	0	0	7.2 - 18V	1.5 - 3.3Ah	Adaptor #193949-2 required to charge all Pod / Stick style batteries
	DC36RA	DC36RA	0	-	-	36V	2.6Ah	
Economy Charger	DC18SD	DC18SD	0	0	-	14.4 - 18V	1.5 - 3.3Ah	Only for Slide-On Type Batteries, Adaptors are not used for this charger.
Standard for Pod / Stick	DC1804	DC1804	-	0	0	7.2 - 18V	1.5 - 3.0Ah	
	DC1414	DC1414	-	0	0	7.2 - 14.4V	1.5 - 3.0Ah	
Automotive	DC18SE	DC18SE	0	0	0	7.2 - 18V	1.5 - 3.3Ah	Adaptor #193949-2 required to charge all Pod / Stick style batteries
	DC1822	DC1822	-	0	0	7.2 - 18V	1.5 - 3.0Ah	Only for Pod / Stick style batteries
For Li-Ion Stick	DC10WA	DC10WA	0	-	-	7.2 - 10.8V	1.0 - 1.3Ah	
	DC07SA	DC07SA	0	-	-	7.2V	1.0Ah	
Built In	DC7020	113051-5	-	-	0	7.2V	1.3Ah	
	DC4100	CACDC4100	-	-	0	4.8V	1.3Ah	

Battery - Charger Kits & Adapters

Part No.	Description	Contents
DC18RAKIT	LXT Battery-Charger Kit	18V Li-Ion 3.0Ah Battery BL1830 (1 ea) & Battery Charger DC18RA
BTC01KIT	Li-Ion & Makstar Diagnostic System	Attaches to any PC to diagnose battery condition. Consult a Makita Sales Rep for further details.
193681-8	ADPO3	Refreshing Adapter for DC14SA, DC18RA and DC24SA for Makstar Batteries
193949-2	ADPO4	Adapts DC18RA, SD and SE to charge pod style batteries

Misc Cordless Tool Accessories

Part No	Description	Features & Benefits / For Model(s) No.
194649-7	Battery Protector	Shock Absorbing Frame for Li-Ion Batteries / BL1430, BL1830
450128-8	Li-Ion Battery Cover	Dust Protection Cover for Li-Ion Batteries / BL1415, BL1430, BL1815, BL1830
451153-2	Li-Ion Battery Cover	Dust Protection Cover for Li-Ion Battery BL3626