


Models/Modelos/Modèles
P1819LF▲
Series/Series/Seria


▲ Specify Finish
Especifique el acabado
Précisez la Finition

RP73805
1.0 GPM (3.8 L/min)
Aerator & Wrench
Aireador y Llave
Aérateur et Clé

RP100116-1.5
1.5 GPM (5.7 L/min)
Aerator & Wrench
Aireador y Llave
Aérateur et Clé




RP63208
Mounting Kit
Juego de piezas para la
instalación Kit de montage



RP93987▲
Escutcheon & Base Plate (3 Hole)
Chapetón y Placa de Base (3 agujeros)
Boîtier et Plaque de Finition (3 trous)

RP63206
Cartridge
Cartouche
Cartucho



RP93985▲
Bonnet Nut & Cap
Écrou de chapeau et Embase
Tuerca bonete y Casquillo

RP93986▲
Handle Kit
Conjunto de manija
Montage de la manette

