








---

**40V LITHIUM-ION CORDLESS LAWN MOWER**

Model: EB137CD



**Parts List**



1. Upper Handle
2. Fasten Screw
3. Lower Handle
4. Grass Catcher
5. Battery
6. Wheels

7. Switch Interlock
8. Foam Pipe
9. On/Off Switch
10. Plastic Stopper
11. Safety Key