


4P-6 4Pin™


**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description	Ref. No.	Catalog No.	Description
1	46923	4P-6 Die Plate	14	47003	Dieless Plunger Asm.
2	46943	Retaining Ring (8)	15	46983	Piston Plunger
3	46933	Torx Screw (2)	16	47038	Alignment Block (2)
4	47008	Warning Decal	17	46998	Filler Block (2)
5	46928	Shoulder Screw (2)	18	46988	Dieless Roller (2)
6	47023	Washer (2)	19	46938	Roller Pin (4)
7	46968	Indenter Holder (2)	20	47033	4P-6 Decal
8	47282	Dowel Pin (2)	21†	47028	Star Nut (2)
9	46948	Spring Pin (13)	22	36387	Roll Pin (2)
10	46958	Dieless Indenter (4)	23	46978	Spring (2)
11	35073	Spring Pin (2)	24	47018	Spring
12	46963	Bearing Block (2)	25	46993	Latch
13	46953	Ball Bearing (24)	26	47013	Latch Grip

†Ref 21. Each Star Nut must be torqued to 25 ft/lbs