



INSTALLATION INSTRUCTIONS for FLOOR BASE ACCESSORIES 4287 & 4288



STEP 1: LAY HEATER ON ITS BACK (SEE ILLUSTRATION BELOW). LOOSEN TWO (2) SCREWS, LOCATED ON BOTTOM OF HEATER - DO NOT REMOVE SCREWS.

STEP 2: ATTACH FLOOR BASE TO HEATER WITH TWO (2) KEYHOLES LOCATED ON TOP OF THE FLOOR BASE. TIGHTEN SCREWS.

USE TWO (2) SCREWS, INCLUDED WITH KIT, TO ATTACH BACK OF FLOOR BASE TO THE BOTTOM BACK OF HEATER.



STEP 3: STAND HEATER UPRIGHT. SELECT LOCATION OF HEATER. REFER TO THE INSTALLATION AND OPERATING INSTRUCTION MANUAL FOR MINIMUM CLEARANCES.

CONNECT GAS PIPING. SEE SECTION "GAS SUPPLY AND PIPING REQUIREMENTS" IN THE INSTALLATION AND OPERATING INSTRUCTION MANUAL.

USE TWO (2) FLOOR MOUNTING SCREWS, (NOT INCLUDED WITH KIT), TO MOUNT THE BOTTOM BACK OF THE FLOOR BASE TO THE FLOOR (SEE ILLUSTRATION ABOVE).

