

# Monterey Blower Accessory

## MODEL 2901


| Reference Number | Description                      | Part Number |
|------------------|----------------------------------|-------------|
| 1                | Screw - #8Ax 3/8 (8)             | ***         |
| 2                | Blower Grille                    | 9C99        |
| 3                | Screw - #8Ax 3/8 (8)             | ***         |
| 4                | Screw - #10 x 1/2                | ***         |
| 5                | Toggle Switch                    | P320911A    |
| 6                | Wire Bridle                      | P320912     |
| 7                | Flat Washer - #10-31 (2)         | ***         |
| 8                | Machine Nut - #8-32 w/Washer (2) | ***         |
| 9                | Blower Body                      | 9C102       |
| 10               | Motor Mount Grommet (2)          | P321078     |
| 11               | Strain Relief Bushing            | ***         |
| 12               | Fan Switch                       | P323097     |
| 13               | Screw - #8-18 x 1/2"             | ***         |
| 14               | Motor                            | P320905     |
| 15               | Fan Blade                        | P320907     |
| 16               | Orifice Plate                    | 9D12-1      |
| 17               | Junction Box Cover               | 9B161       |

## MODEL 2907

| Reference Number | Description               | Part Number |
|------------------|---------------------------|-------------|
| 1                | Blower Grille             | 9C99        |
| 2                | Orifice Plate             | 9B246       |
| 3                | Wire Assemblies           | 9B248       |
| 4                | Blower and Motor          | P323076     |
| 5                | Heat Sensor Wire Assembly | P320912     |
| 6                | Junction Box Cover        | 9A483       |
| 7                | Fan Switch                | P323080     |
| 8                | Blower Body               | 9B249       |
| 9                | Heat Sensor Switch        | P323097     |

# Direct-Vent Wall Furnace

Model Numbers: 1403821, 1413821, 1433821, 1453821, 1403822, 1413822, 1433822, 1453822




## CABINET PARTS

| Reference Number | Description                                       | 1403821<br>1413821<br>1433821<br>1453821 | 1403822<br>1413822<br>1433822<br>1453822 |
|------------------|---------------------------------------------------|------------------------------------------|------------------------------------------|
| 1                | Face Panel                                        | 4309                                     | 4309                                     |
| 2                | Combustion Chamber Shield                         | 8A72                                     | 8A72                                     |
| 3                | Combustion Chamber                                | 8B77                                     | 8B77                                     |
| 4                | Flue Tube Gasket (2 Required)                     | P147001                                  | P147001                                  |
| 5                | Inner Casing                                      | 8B62                                     | 8B62                                     |
| 6                | Air Inlet Gasket                                  | P147000                                  | P147000                                  |
| 7                | Air Inlet Shield (Standard Maximum 9" Thick Wall) | 6C54-1                                   | 6C54-1                                   |
| 8                | Vent Cap                                          | 9306                                     | 9306                                     |
| 9                | Air Inlet Collar (Standard Maximum 9" Thick Wall) | 6C60                                     | 6C60                                     |
| 10               | Flue Extension (Standard Maximum 9" Thick Wall)   | 6A193                                    | 6A193                                    |
| 11               | Mounting Spacer Plate                             | 8B64                                     | 8B64                                     |
| 12               | Air Inlet Gasket                                  | P121800                                  | P121800                                  |

# Direct-Vent Wall Furnace

Model Numbers: 2203831, 2213831, 2233831, 2253831, 2203822, 2213822, 2233822, 2253822



| CABINET PARTS    |                                                   |                                          |                                          |
|------------------|---------------------------------------------------|------------------------------------------|------------------------------------------|
| Reference Number | Description                                       | 2203821<br>2213821<br>2233821<br>2253821 | 2203822<br>2213822<br>2233822<br>2253822 |
| 1                | Face Panel                                        | 4313                                     | 4313                                     |
| 2                | Combustion Chamber Shield                         | 6B149                                    | 6B149                                    |
| 3                | Flue Tube Gasket (2 Required)                     | P147001                                  | P147001                                  |
| 4                | Flue Extension (Standard Maximum 9" Thick Wall)   | 8A51                                     | 8A51                                     |
| 5                | Air Inlet Gasket                                  | P147000                                  | P147000                                  |
| 6                | Air Inlet Collar (Standard Maximum 9" Thick Wall) | 6C60                                     | 6C60                                     |
| 7                | Mounting Spacer Plate                             | 6C66                                     | 6C66                                     |
| 8                | Air Inlet Shield (Standard Maximum 9" Thick Wall) | 6C54-1                                   | 6C54-1                                   |
| 9                | Vent Cap                                          | 9306                                     | 9306                                     |
| 10               | Inner Casing                                      | 6D20                                     | 6D20                                     |
| 11               | Air Inlet Gasket (2 Required)                     | P121800                                  | P121800                                  |
| 12               | Combustion Chamber                                | 6304                                     | 6304                                     |
| 13               | Leg Cover Plate                                   | 6B25                                     | 6B25                                     |
| 14               | Bottom Heat Shield                                | -                                        | -                                        |